

PRODUCT INFORMATION

SERVAPOR® 6 MWCO 6000 - 8000 **Cat. No.: 44561**

PRODUCT DESCRIPTION

SERVAPOR® dialysis tubings are made of regenerated cellulose (RC). The membranes excel in high mechanical stability and show minimal contamination.

Application Desalting, buffer exchange, removal of small molecular impurities

Dialysis Procedure

- Calculate length of tubing needed with the help of the given filling volume (ml/cm). Allow at least 10 % additional length for sample expansion and 2 - 4 cm on either end for closures.
 - Wear gloves and cut the tubing into the desired length.
 - Soak tubing in dist. H₂O for 15 – 20 min.
 - Rinse thoroughly in clean dist. H₂O
 - Close one end of the tubing with a closure.
 - Pipet the sample in the tubing.
 - Close the other end of the tubing also by using a closure.
 - Immerse the tubing in dialysis buffer
 - Low-molecular salts and buffers (Tris-HCl, NaCl) equilibrate within 3 hours. Equilibration times for viscous samples will be longer.
 - Change dialysis buffer as necessary, at least 2-3 times
 - After dialysis is completed, remove the tubing from the buffer solution, release on closure and collect the sample carefully.
-

Membrane pre-treatment to remove traces of sulphur and heavy metals

- Cut the membrane into the desired length, fully immerse it in 1 L aqueous solution of 2 % (w/v) NaHCO₃ and 1 mM EDTA using a 2 L glass beaker.
 - Boil the membrane in the solution for 10 min.
 - Rinse thoroughly in dist. H₂O.
 - Transfer the membrane in another 2 L glass beaker, add 1 L dist. H₂O and boil it for 10 min.
 - Remove the water and add 50 % Ethanol/1 mM EDTA solution to submerge the membrane fully.
 - Then the membrane can be stored in 50 % Ethanol/1 mM EDTA solution at + 4 °C.
 - Rinse thoroughly with dist. H₂O prior to use.
-

Storage Store dry membrane at + 15 °C to + 30 °C.

Ver. 07/15
